


Two Wings - Door and window measuring instructions Flat running rail



1. Two Wings - Door and window measuring instructions with a flat running track (without roller shutter)


Please pay attention to the instructions on how to measure a fly screen with a flat track without a roller shutter.



2. Two Wings - Width

1. if the window outer frame is more than 3.5mm+ on both sides, then we measure as in point 2

2. if the window outer frame is less than 35mm on both sides, then we measure from the area (between shutter and window) from right to left. You should subtract 10mm from the width so that the fly screen can be fitted easily.




3. Two Wings - Height

In this case we measure the height from the floor to the outer frame edge of the door and add +35mm.

(Please note that the floor may have a slope, you could subtract 5mm from the total height to better fit the fly screen)

Example: 2000mm + 35mm = 2035mm




4. Two Wings - Measurement Result

This picture is a summary of how to measure the width and height.


Alle Produkte nach Maß von DEKORSSS

Example Width $1500\text{mm} + 35\text{mm} + 35\text{mm} = 1570\text{mm}$
 Height $2000\text{mm} + 35\text{mm} = 2035\text{mm}$



5. Two Wings - Custom Fly Screens


Example Width 1570mm
 Height 2035mm



6. Two-wing fly screen is mounted with a flat running rail.

The fly screen is attached to the window/door and screwed in with 4 small screws each. Alternatively, double-sided adhesive tape can also be used. The fly screen has two wings and is pulled from the right and left sides and closed with a magnet. (Please note that the adhesive tape needs to be renewed after some time). Please make sure that the thin rail is flush with the floor. The fly screen is mounted between the window/door.


If there is not enough space +35 mm, follow these instructions



1. Two Wings - Width


If there is less than 35 mm space between the blind guide rails and the window, the calculation is carried out as shown here.

For example, there is a distance of 20 mm on the right-hand side and a distance of 21 mm on the left-hand side, as shown in the picture.



2. Zwei Flügel - Höhe

As shown here, the drain cover is also measured to the top edge of the edge profile and then 20 mm is added as there is a 20 mm gap. Then you can go and place the order for the second product.



3. Two Wings - Measurement Result

Example Width $1500\text{mm} + 20\text{mm} + 21\text{mm} = 1541\text{mm}$
 Height $2000\text{mm} + 20\text{mm} = 2020\text{mm}$