



Measurement Instructions for Flat Running Rail Between Roller Shutter and Door Frame (minimum 20 mm Distance)



1. Door and Window: Measurement Instructions for Flat Running Rail Opening from Left or Right (with Roller Shutter)

This concerns a window/door with a roller shutter. Please note that if there is a minimum of 2cm distance between the window and the guide rail, then the fly screen can be installed between the roller shutter and the window.




2. Width (for thin rail)

Here are two options for measurement:

2.1 If the outer window frame exceeds 3.5mm+ on both sides, then we measure as in point 2.

2.2 If the outer window frame is less than 35mm- on both sides, then we measure from the area (between the roller shutter and the window) from right to left. You should subtract 10mm from the width so that the fly screen can be easily attached.


Example $900\text{mm} + 35\text{mm} + 35\text{mm} = 970\text{mm}$



3. Height (for thin guide rail)

In this case, we measure the height from the floor to the outer frame edge of the door and add +35mm. (Please note that the floor may have a slope, so you could subtract 5mm from the total height to better fit the insect screen). The thin rail of the insect screen is 10mm deep.


Example $1900\text{mm} + 35\text{mm} = 1935\text{mm}$



4. Type and Window Measurement Guide Measurement Result

This picture is again a summary of how to measure the width and height. See images 2 and 3.

Example Width $900\text{mm} + 35\text{mm} + 35\text{mm} = 970\text{mm}$
 Height $1900\text{mm} + 35\text{mm} = 1935\text{mm}$




5. Custom-made fly screens spelling

Example Width 970mm and Height 1935mm




6. Fly screen is mounted with a flat running rail (from the right)

The fly screen is attached to the window/door and secured with 4 small screws each. Alternatively, double-sided tape can also be used (please note that the tape needs to be renewed after some time). Please ensure that the thin rail is flush with the floor. The fly screen is mounted between the window/door.




1. Two Wings - Width

If there is less than 35 mm space between the blind guide rails and the window, the calculation is carried out as shown here. For example, there is a distance of 20 mm on the right-hand side and a distance of 21 mm on the left-hand side, as shown in the picture.



2. Two Wings - Height

As shown here, the drain cover is also measured to the top edge of the edge profile and then 20 mm is added as there is a 20 mm gap. Then you can go and place the order for the second product.



3. Two Wings - Measurement Result

Example Width $900\text{mm} + 20\text{mm} + 21\text{mm} = 941\text{mm}$
 Height $1900\text{mm} + 20\text{mm} = 1920\text{mm}$